


DONART ELECTRONICS  
IRT INTERLAMINAR RESISTANCE  
TESTER MANUAL



User's Guide

# Contents

<b>LIMITED EXPRESS WARRANTY .....</b>	<b>i</b>
<b>SOFTWARE LIMITED WARRANTY AND DISCLAIMER LIABILITY .....</b>	<b>i</b>
<b>SOFTWARE LICENSE .....</b>	<b>ii</b>
<b>SAFETY PRECAUTIONS .....</b>	<b>ii</b>
<b>AMBIENT TEMPARTURE .....</b>	<b>ii</b>
<b>1 Getting Started.....</b>	<b>1</b>
Introduction.....	1
<b>2 Installation .....</b>	<b>2</b>
Interlaminar Tester Front View .....	2
Interlaminar Tester Rear View.....	2
Interlaminar Tester Overview.....	3
Interlaminar Tester Setup.....	3
<b>3 Operation .....</b>	<b>5</b>
System Turn on.....	5
Donart Interlaminar Resistance Software .....	6
Main Screen .....	6
Test Data Section .....	7
Meters section .....	8
Measurements Section .....	9
Statistics Section .....	10
Buttons Section .....	11
Settings Menu .....	12
Calibration/Manual Menu .....	12
Save Files.....	13

4 Maintenance .....	14
Fuses .....	14
Drill Bits .....	15
Sample Shelf Insulation .....	20
5 Specifications .....	23
Measurable Materials.....	23
Test Data Reported.....	23
Measurement accuracy .....	23
Test Pressure .....	23
Measuring Currents.....	23
Fuses.....	23
Operating Voltage .....	23
Operating temperature .....	23
Air supply .....	23

**LIMITED EXPRESS WARRANTY**

Seller will at its option repair or replace (FOB Seller's place of business) any part of the goods sold hereunder which it determines to be defective within one year of the date of shipment by the Seller. This warranty is subject to the following conditions: (a) that Seller is notified by Purchaser of such defect within ten days of the discovery of the same, (b) that the goods and/or components have been properly installed, maintained, and operated under normal conditions and in accordance with the recommendations of the Seller and standard industry practice: (c) that this warranty shall extend only to the original direct purchaser from Seller and to no other person. Such reworking or replacement will be performed at Seller's factory, provided that Purchaser shall pay all charges with respect to the removal, transportation and reinstallation of the goods. Correction of any nonconformity in the manner and for the period of time provided above shall constitute complete fulfillment of all liabilities of Seller under the foregoing warranty. EXCEPT FOR THE FOREGOING LIMITED EXPRESS WARRANTY, SELLER MAKES NO OTHER REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

Seller shall not be liable to Purchaser or any third party in contract, in tort (including negligence) or otherwise for any direct, indirect contingent, special, consequential or incidental damages, arising out of any operation of defects in the goods sold hereunder, or any matter or thing relating to this agreement or Seller's performance hereunder. Seller's liability on any claim of any kind, including claims based upon Seller's negligence or Seller's warranty as described above, for any damages arising out of this contract, or from the manufacturer, sale, repair or use of any goods furnished under this contract shall in no case exceed the purchase price allocable to the goods or part thereof which gives rise to the claim.

Purchased equipment or instruments included as a part of this system shall be subject to the warranty of the manufacturer of that equipment. No other warranty shall be added or implied to such equipment.

**SOFTWARE LIMITED WARRANTY AND DISCLAIMER LIABILITY**

Donart Electronics, Inc., hereinafter referred to as "Donart", has no control over licensee's use of the software, therefore Donart does not and cannot warrant the performance or results that may be obtained by its use. However, Donart provides the following limited warranty:

**WHAT IS COVERED:**

DONART warrants that the magnetic diskette(s) which the enclosed computer software is recorded on and the documentation provided with it are free from defects in materials and workmanship under normal use. DONART warrants that the computer software itself will perform substantially in accordance with the specifications set forth in the documentation provided with the software.

**FOR HOW LONG:**

The above warranties are made for sixty (60) days from the date of original delivery to you or your company as the user:

**WHAT WE WILL DO:**

DONART will replace any magnetic diskette or documentation which proves defective in materials or workmanship without charge.

DONART will either replace or repair any software that does not perform substantially in accordance with the specifications set forth in the documentation, with a corrected copy of the software or corrective code. In case of an error in the documentation, DONART will correct errors in the documentation without charge by providing addenda or substitute pages.

**WHAT WE WILL NOT DO:**

DONART does not warrant that the functions contained in the software will meet your requirements or that the operation of the software will be uninterrupted or error free. The warranty does not cover any diskette or documentation which has been subjected to damage or abuse. The software warranty does not cover any software which has

been altered or changed in any way by anyone other than DONART.

DONART is not responsible for problems caused by or in conjunction with non-DONART software.

ANY IMPLIED WARRANTIES COVERING THE DISKETTE, THE DOCUMENTATION OR THE SOFTWARE PROGRAM INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO SIXTY (60) DAYS FROM THE DATE OF ORIGINAL DELIVERY. An implied warranty of merchantability means that the product will work normally, and an implied warranty of fitness means that a product is suitable for the use for which it is advertised. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

DONART SHALL NOT IN ANY CASE BE LIABLE FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, INDIRECT OR OTHER SIMILAR DAMAGES ARISING FROM BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, OR ANY OTHER LEGAL THEORY EVEN IF DONART OR ITS AGENT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This means we are not responsible for any costs incurred as a result of lost profits or revenue, loss of use of the software, loss of data, costs of recreating lost data, the cost of any substitute program, claims by any party other than you, or for other similar costs. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**WHAT YOU MUST DO:**

You must return the defective item postpaid within sixty (60) days of the software's original delivery to you, and we must receive it within seventy-five (75) days of delivery. You must either insure the defective item being returned or assume the risk of loss or damage in transit. Address all warranty claims to: Donart Electronics, Inc., P. O. Box 27, McDonald, PA 15057 USA.

**OTHER CONDITIONS:**

This warranty allocates risks of product failure between you and DONART. DONART'S software

pricing reflects this allocation of risk and the limitations of liability contained in this Warranty. The warranty set forth above is in lieu of all other express warranties, whether oral or written. The agents, employees, distributors and dealers of DONART are not authorized to make modifications to this warranty, or additional warranties binding on DONART. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by DONART and should not be relied upon.

**STATE LAW RIGHTS:**

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**SOFTWARE LICENSE**

Donart Electronics, Inc. grants to the purchaser the license to use this product on the supplied system by any authorized operator. The software remains the property of Donart Electronics, Inc. whether modified or not.

Donart does not grant the right to make copies or supply copies of the software to any person other than those required to operate the system regardless of the method of making these copies or distributing the copies without the written consent of Donart Electronics, Inc. Any changes made by the purchaser or by outside vendors to the supplied programs do not invalidate Donart's right and license to this product.

In accepting this system and software, it is agreed that the purchaser will maintain the design of both hardware and software confidential except as necessary to train operators and operate the system.

**COMMERCIAL SOFTWARE SUPPLIED WITH THIS SYSTEM**

All commercially supplied software, if accepted, shall bind the user to the terms of the licensing agreement supplied by this software. Donart has purchased and supplied such software as was considered necessary or convenient for proper system operation. Such software has been supplied complete with instructions and license.

**SAFETY PRECAUTIONS**

The test console is a complex measuring system composed of a number of independent instruments and devices operated directly from or through appropriate transformers connected to a main AC power line source. Internal wiring as well as components and wiring internal to the various instruments represent potential electrical shock hazard to personnel. The instrument should not be installed or operated until all personnel concerned with installation, operation and maintenance are made aware of these potential hazards. In addition to the suggestions contained herein, all local electrical and mill codes should be carefully adhered to by properly trained personnel concerning the installation, operation and maintenance.

**HAZARDOUS VOLTAGES**

The exact reaction to an electrical shock can range from mild annoyance or discomfort to death. Effects of an electrical shock depend on the source of the shock, the physical condition of the individual encountering the shock, the length of time encountered, how good the electrical contact is and the individual's natural reaction to the shock among other variables. In addition to the hazard of the shock to the person receiving it, there is also the possibility of personal injury due to the physical reaction in attempting to quickly escape from the contact. As an example, voluntary or involuntary reaction to the shock can cause an individual to strike his head or other parts of his body against a cabinet or physical obstruction causing physical injury or death in addition to the specific damage caused by the shock.

In general, persons wearing pacemakers or other electrical or electronic life aid devices should not perform maintenance or operate equipment using line voltage as a primary power source. Since even mild electrical shocks can disrupt the bodies normal nerve messages, persons with nervous disorders or heart conditions should not maintain or operate this equipment.

**ABOVE NORMAL BODY TEMPERATURES**

Under normal operating conditions, only a few of the components in the instrument are hot enough to be uncomfortable to touch or possibly cause burns. Jerking away or

otherwise reacting to contact with these parts could cause injury to parts of the body coming in contact with the cabinet or other physical obstructions. Allow the instrument to cool before performing maintenance.

In general, both transformers and motors operate normally at higher than body temperatures and contact with these without proper thermal protection should be avoided. In the event of equipment malfunctions or failure of parts, higher than normal temperatures could result in not only the above-named components, but additionally in wires, resistors and other normally cool parts. In the case of equipment malfunctions, exercise extra care to avoid the possibility of contact with above body temperature parts.

**AMBIENT TEMPARTURE**


The test console contains electronic circuitry; some portions of which are by nature temperature sensitive. The system will not maintain its full accuracy over a large temperature range. The ideal location for the unit is in an air-conditioned room. It is recommended that an attempt be made to maintain the ambient temperature at 72°F (22.2° C), plus or minus 2°F (1.0°C). The instrument should be turned on for at least 1 hour for stabilization prior to any measurement.

# 1 Getting Started

## Introduction

The model IRT1 Interlaminar Resistivity Tester is an advanced instrument for measuring the interlaminar resistance of electrically insulating coatings of adjacent electrical steels. This tester follows and conforms to all requirements in ASTM standard A937.

To measure an average interlaminar resistance a known area has to be defined. This is achieved by stacking the two laminations and applying pressure using two 10cm<sup>2</sup> pads. An overview of this can be seen below.




Once pressure is applied to the laminations, the tester then uses two sets of drill bits for setting current and concurrently measuring voltage. Drill bit 1 pierces the top insulation surface A, with drill bit 2 piercing the bottom insulation surface B. This allows a constant current to flow through the defined interlaminar insulation area C. Drill bits 3 and 4 then also pierce the top and bottom insulations respectively but they are used to measure the voltage drop across the interlaminar insulation.

Since the constant current is known, the voltage measurement can be used to calculate interlaminar resistance using Ohm's law which is,  $Resistance = Voltage/Current$ .


## 2 Installation

The IRT Tester comes assembled so the only installation is to install the computer system, connect air and power to tester and read the following overview to identify system components.

### Interlaminar Tester Front View



### Interlaminar Tester Rear View




## Interlaminar Tester Overview



## Interlaminar Tester Setup

1. Set up the computer by connecting power and the HDMI cable to the monitor and then plugging the other end of the HDMI to the video card on the computer.





2. Plug the wireless mouse/keyboard receiver into the front of the computer and then plug one end of the USB B cable into the rear of the computer in an open USB slot.



3. Plug the other end of the USB-B cable into the IRT Tester, along with the power cable and air. Power must be 120/220 VAC and air must a minimum of 60 PSI, Clean and water trapped.




### 3 Operation

#### System Turn on

1. Flip the power switch to the on position on the front of the IRT Tester. Its light will glow green



2. Select the Donart Interlaminar Tester program from the desktop to load the program.



## Donart Interlaminar Resistance Software

Donart Interlaminar Resistance software allows the user to control the tester and make resistance measurements from a personal computer. The software automatically calculates resistance and other statistics as well as allows saving of data locally and over a network.

### Main Screen

The screenshot shows the main interface of the Donart Interlaminar Resistance Software. It features a top menu bar with 'File' (6) and 'Options' (7). The main area is divided into several sections: 'Test Data' (1) for entering sample information, 'Measurements' (2) for recording resistance values in a table, 'Meters' (3) for real-time measurement display, 'Statistics' (4) for calculation of test results, and a set of control buttons (5) including 'START', 'SAVE', and 'CLEAR'. The Windows taskbar is visible at the bottom.

#### ① Test Data

Allows the user to enter test data for each sample being tested

#### ② Measurements

Section for obtaining a number of resistance measurements for a sample

#### ③ Meters

Allows user to watch current, voltage and resistance measurements during test

#### ④ Statistics

Automatic calculation of test measurement statistics

#### ⑤ Buttons

Used for controlling tester, saving and clearing of data

#### ⑥ File Menu

For exiting and saving

#### ⑦ Options Menu

For calibration, manual controls and settings


## Test Data Section

The test data section allows the user to enter informational data for the sample being tested. This test data is saved along with measurements from the current sample. All fields have a max of 10 characters except for comments which has a max of 200.


Test Data					
Tester ID	<input type="text"/>	Ingot ID	<input type="text"/>	Coating Type	<input type="text"/>
Order Number	<input type="text"/>	Lot Number	<input type="text"/>	Cycle Number	<input type="text"/>
Order Item Number	<input type="text"/>	Coil Number	<input type="text"/>	Adhesive	<input type="text"/>
Heat Number	<input type="text"/>	Test Date	08-19-2020	Application Method	<input type="text"/>
Comments	<input type="text"/>				

- Tester ID  
Unique identification for user currently operating test.
- Order Number  
Order number for sample
- Order Item Number  
Order Item number for sample
- Heat Number  
Heat number for sample
- Ingot ID  
Ingot identification
- Lot Number  
Lot number sample was obtained from
- Coil Number  
Coil sample was obtained from
- Test Date  
Date sample was tested which is filled automatically
- Coating Type  
Selectable between Inlac, Oxide, Other
- Cycle Number  
Cycle sample obtained from
- Adhesive  
Adhesive used on sample
- Application Method  
Application method used on sample
- Comments  
Section for entering comments for sample

## Meters section



The meters section allows the user to monitor measurements during testing. It allows for monitoring of current, voltage (across drill bits 3&4) and resistance calculated from current and voltage measurements. The measurements are constantly updated in real time.



By clicking the appropriate tab on the meter, the user can switch between all three measurements. By clicking Drills 3&4, the meter will display volts which can be seen above.

## Measurements Section

**Measurements**

	1	2	3	4	5	6	7	8	9	10
► Resistance										

The measurements section allows the user to perform a number of resistance measurements for a sample. Data is automatically populated during the test in each cell. As seen above, the measurements section allows for ten measurements across a sample.

**Measurements**

	1	2	3	4	5	6	7	8	9	10
► Resistance										

To populate a cell with a measurement, click the cell to highlight it and then click the start button. The tester will apply force to the sample and begin testing. Once the test is finished, the highlighted cell will be populated and then the next cell to the left will be highlighted.

**Measurements**

	1	2	3	4	5	6	7	8	9	10
► Resistance	1181708	995673.8	1211039							

**Measurements**

	1	2	3	4	5	6	7	8	9	10
► Resistance	1181708	1225707	1211039							

A measurement can be changed in the same manner. To retest a measurement, simply click the measurement you want to change and click start button. Once test is finished, the measurement will be updated and the next blank cell or last measurement will be highlighted.

## Statistics Section

Statistics		
Max	1225707	
Min	1181708	
Average	1206151	
Surface Resistance	12061.51	$k\Omega \cdot cm^2$

The statistics section contains stats that are calculated from the all the resistance measurements. They are automatically calculated during testing and saved along with test data and measurements.

- Max  
Highest resistance measured out of all measurements
- Min  
Lowest resistance measured out of all measurements
- Average  
Average resistance calculated from all measurements
- Surface Resistance  
Two surface insulation resistance calculated from the average in units of  $k\Omega \cdot cm^2$


## Buttons Section



- Start/Abort  
Starts test and applies pressure/current to sample. Once clicked it will turn to an abort button to cancel test.
- Save  
Saves Test data and measurements locally and over network
- Clear  
Clears all entered test data, measurements and statistics



## Settings Menu



The settings screen can be accessed by clicking options from the menu bar and then clicking settings. The settings screen allows the user to change the following save file locations.

- Local Datfile Save File Location  
Changes the save file location for local datfile strings
- Network Datfile Save File Location  
Changes the save file location for network datfile strings
- As Screened Save File Location  
Changes the save file location for as screen save files

To revert settings back to default. Click the defaults button then click save

## Calibration/Manual Menu

The calibration and manual control screens can be accessed by clicking options from the menu bar and then clicking calibration/manual controls. These two screens are password protected and meant only for Donart Technicians or authorized users.

The calibration menu contains all necessary instructions and procedures for calibration of IRT Tester.

The manual controls menu allows the user to manually control all features of the system.

### Save Files

The IRT software saves two different types of files. Files are saved with the data being formatted for easy reading which are referred to as “as screened save files”. The other types are known as “dat files”. Dat files are saved as comma delimited string files that can be saved locally and over the network, so they can be parsed and entered into a database, excel, etc.

### As screened Save Files

As screened save files as seen above are easily readable containing all measurements and test data. These files can be opened in any text editor program. The save file location can be edited in the IRT software settings

### Local and Network Datfiles

Datfiles are saved in two locations which can be edited in the IRT software settings. They are comma delimited and can be parsed as follows.


1	2	3	4	5	6	7	8	9	10	11	12	13
Tester ID	Order Number	Order Item Number	Heat Number	Ingot ID	Lot number	Coil Number	Test Date	Coating Type	Cycle Number	Adhesive	Application Method	Comments

14	15	16	17	18	19	...	...	17+x
Test Max	Test Min	Test Average	Test Surface Resistance	Measurement 1	Measurement 2	...	...	Measurement x

## 4 Maintenance

### Fuses

The IRT Tester has two fuses that may need to be replaced. They are 250 V 2A 5x20mm Fast Acting fuses available online (<https://www.mouser.com/ProductDetail/576-0217002.MXP>) or at any automotive store.



The fuses are located in the back of the tester on top of the power plug. Simply insert a screw driver to open the door and replace them when needed.

## Drill Bits

The Drill bits will need to be replaced periodically once they no longer are cutting through the insulation. The user will be notified once they need replaced, through software since every test performs a drill bit check.

The drill bits can be ordered directly from Donart and when they need replaced the following procedure can be followed.


Tools needed:

- Phillips screwdriver
- 1/16" Hex key
- 5/64" Hex Key
- Cut resistant gloves (Drill bits are very sharp!!)
- Wire cutters
- Zip ties x 4

1. Unplug power, USB and air supply from tester.




2. Remove the four securing the front guard along with the two screws securing the bottom cover panel using a philips screwdriver




3. Cut the wire tie supporting the cable on the actuator



4. Loosen the two set screws on a sense collar to remove it and move it out of the way using a 1/16" hex key.




5. Loosen the set screw on the actuator and the drill bit can then be removed using the 5/64" hex key



6. Insert new drill bit into the actuator and tighten set screw to secure it




7. Slide sense collar back on to new drill bit and tighten its two set screws






8. Wire tie wire back on to actuator



9. Repeat steps 3-8 for each new drill bit  
10. Reinstall front guard and panels using six screws





## Sample Shelf Insulation

The sample shelf has a protective insulation film on it to prevent laminations from shorting to the shelf. If a lamination shorts to the shelf, the tester will not measure resistance correctly so it is important to inspect the insulation periodically for cuts or nicks and replace as needed.

The shelf can be removed by following the following procedure.


Tools required

- Phillips screwdriver
- Wire cutters
- Zip ties x 2

1. Unplug power, USB and air supply from tester.




2. Remove the four securing the front guard along with the two screws securing the bottom cover panel using a philips screwdriver



3. Remove the four screws securing the shelf to the angles using a Philips screwdriver.



4. The IR receivers are attached to the shelf so cut the wire tie below and unplug them so they can be removed with the shelf.



5. The shelf can now be removed by sliding it out the front of the tester. The old insulation film can be scraped off and the new one applied.

## 5 Specifications

Measurable Materials	Minimum 12" Long laminations having electrically insulation coating on each side  Coatings of insulation resistivity in excess of $0.3 \text{ k}\Omega \cdot \text{cm}^2$ (Franklin Values of 0.02A or Greater)
Test Data Reported	Resistance, interlaminar two surface resistance, min/max/average from total measurements
Measurement accuracy	Meets or exceeds ASTM Specifications A937
Test Pressure	300 PSI
Measuring Currents	10 $\mu$ A, 1 $\mu$ A, 0.8 $\mu$ A
Fuses	Cartridge Fuses 250 V 2A 5x20mm Fast Acting
Operating Voltage	120/220 VAC
Operating temperature	70°F $\pm$ 10°F
Air supply	Minimum 60 PSI, Clean, water trapped air supply required